

026121-03 - AquaHarvest Domestic RWH Pictorial Installation Document (Direct System).






026121-03 - AquaHarvest Domestic RWH Pictorial Installation Document (Direct System).




Ensure All Items Received Un-Damaged




Excavate Hole To Suit Tank



Lower Tank Into Excavation




Backfill/Ballast In Stages To **Support Tank**



Connect Inlet/Overflow/Vent/Duct.

Step 6 - External



Connect RWH Supply & Mains Top Up MDPE Pipe






Fit Pump to the Manifold inside the Tank

Step 8 - Internal




Secure Mains Top Up Float to bracket with cable tie

Step 9 - Internal



Mains Top Up Float to be positioned 150mm from base

Step 10 - External



Re-fit tank lid and lock using keys supplied

Step 11 - Internal



Join MDPE to RWH Supply **Pipe**

Step 12 - Internal



Connect Inline Filter & Shut Off Valve

Step 13 - Internal




Connect Pressure Vessel (If required)

Step 14 - Internal



Connect Mains Top Up via Solenoid Control valve

Step 15 - Internal





Refer to DS1333P to Connect Pump Isolator, Panel, Float, Solenoid & Fused Spur